



Senergy Holdings – Driver Induction Guide

This Driver Induction Guide provides mandatory safety and operational instructions for all drivers entering and operating within Senergy Holdings' facilities. It is designed to ensure compliance, safety, and efficiency in logistics operations.

1. Site Entry Requirements

- All drivers must present valid identification and delivery documentation.
- Vehicles are subject to inspection at security checkpoints.
- Drivers must wear required Personal Protective Equipment (PPE) at all times.
- Speed limits within the facility must be strictly observed.

2. Loading and Unloading Procedures

- Only trained personnel may operate loading/unloading equipment.
- Drivers must remain in designated safe zones during loading/unloading.
- Wheel chocks and safety barriers must be used before operations begin.
- Spillage prevention procedures must be followed at all times.

3. Safety and Emergency Rules

- Smoking and use of mobile phones are prohibited in operational areas.
- In case of emergency, follow instructions of site safety officers.
- Report all incidents, near misses, or unsafe conditions immediately.

- Emergency assembly points are clearly marked throughout the facility.

4. Vehicle Standards

- Vehicles must be well-maintained, roadworthy, and free from leaks.
- All safety equipment (fire extinguisher, first aid kit, spill kit) must be available.
- Tankers must comply with ADR/IMO standards for hazardous goods.
- Documentation for vehicle inspection must be up to date.

5. Contact Information

Senergy holding company kpsc

Po box 9920| ahmadi 61010| kuwait

East ahmadi| block 8| plot 42| mezzanine

| Email: info@senergy.com

